









Instabili / Momentary

Descrizione / Description	Operatore / Operator	Attuatore / Actuator	Dimensioni mm / Dimensions mm
 Bottone rasato / Flush guard	 PR-010M22 ①	 ATT-804A ATT-804G ATT-804V	
 Bottone sporgente / Extended button	 PR-020M22R	 ATT-805A ATT-805B ATT-805G ATT-805N ATT-805V	
 Fungo assiale / Mushroom head	 PR-050M22R PR-050M22N		
 Fungo oscillante / Wobble mushroom head	 PR-055M22R (ø 40 mm) PR-055M22N (ø 40 mm) PR-056M22R (ø 60 mm)		
 Leva oscillante / Wobble joystick	 PR-054M22R		
 Ripristino / Reset	 PR-255M22A	 ATT-804A ATT-804B ATT-804G ATT-804N ATT-804R ATT-804V senza simboli without symbols	

Stabili / Maintained

Descrizione / Description	Operatore / Operator	Attuatore / Actuator	Dimensioni mm / Dimensions mm
 Bottone rasato passo-passo protetto Flush guard push-on/push-off	PR-030M22 ② Attuatore da ordinarsi separatamente Actuator to be ordered separately	 ATT-728A ATT-728B ATT-728G ATT-728N ATT-728R ATT-728V	
 Fungo passo-passo / Mushroom head push-on/push-off	 PR-045M22R PR-045M22N		
 Fungo sbocco a rotazione / Mushroom head turn to reset	 PR-065M22R (ø40 mm) PR-066M22R (ø60 mm)		